BMW Motorcycles
Maintenance Schedule

☐R 1150 R ☐R 1100 S ☐R 1150 RT ☐R 1150 GS ☐R 1200 C

Customer Name / Repair Order Number / Date Vehicle Identification Number (VIN) / Mileage In	BMW Inspection 600 miles	BMW Service 6,000 miles	BMW Inspection 12,000 miles	BMW Annual Service
Check Vehicle History for any outstanding recalls.	☐	☐	☐	☐
Read Motronic fault memories with BMWMoDiTeC	☐	☐	☐	☐
• *Integral ABS equipped* - Perform bleed test with BMWMoDiTeC. (Print test results, attach to RO and file in Vehicle History File)	☐	☐	☐	
Check Brake pads and discs for wear, renew as necessary*		☐	☐	
Check condition of tires	☐	☐	☐	☐
Check ABS sensors/pulse wheels for correct gap/contamination Adjust and clean as required *	☐	☐	☐	☐
Check front/rear brake fluid levels, top up if necessary* Check brake system with regard to function, leaks, repair as required *	☐	☐	☐	
• Non ABS & ABS II ONLY - Change brake fluid once a year with DOT 4 Fluid*.				☐
• *Integral ABS equipped* - Replace brake fluid in wheel circuit once a year (DOT 4).				☐
• *Integral ABS equipped* - Replace brake fluid in control circuit every 2 years (DOT 4).*				☐
• *Integral ABS equipped* - Perform bleed test with BMWMoDiTeC. (Print test results, attach to RO and file in Vehicle History File)				☐
Check clutch operating fluid level. (fluid level increases as clutch wears)	☐	☐	☐	
Change clutch operating fluid every 2 years (DOT 4 brake fluid).*				☐
Re-torque cylinder head nuts (torque to 20 Nm, then 180°)	☐			
Check/adjust valve clearances	☐	☐	☐	
Check condition of spark plugs		☐		
Replace spark plugs			☐	
Change engine oil when at operating temperature, renew oil filter. (for short distance driving or when outside temperature is below 32 F every 3 months or 1800 miles.)	☐	☐	☐	☐
Change transmission oil when at operating temperature. (or every 2 years at the latest)			☐	☐
Change oil in rear drive when at operating temperature. (or every 2 years at the latest)	☐		☐	☐
Non ABS & ABS II Only- Clean inductive speed sensor at rear drive. (or every 2 years at the latest) R 1200 C, R 1100 S	☐		☐	
Renew Poly-V belt every 36,000 miles*. Do not adjust.			☐	
Check/adjust throttle cable play; any sticking, abrasion, tightness; replace*	☐	☐	☐	☐

* invoiced as a separate item

⇩ Continue on page 2 ⇩

BMW Motorcycles
Maintenance Schedule (Continued)
☐R 1150 R ☐R 1100 S ☐R 1150 RT ☐R 1150 GS ☐R 1200 C

_____
Vehicle Identification Number (VIN)

	BMW Inspection 600miles	BMW Service 6,000miles	BMW Inspection 12,000miles	BMW Annual Service
Renew fuel filter every 24,000 miles*; if fuel quality is poor every 12,000 miles.			☐	
Check battery acid level, top up with distilled water if necessary; grease battery terminal posts.			☐	☐
Renew intake air filter (if riding in dirty/dusty conditions every 6,000 miles/check more frequently)			☐	
Check torque of the rear wheel retaining bolts_____Lb/ft ____Nm. (76 lb/ft 105Nm)	☐			
Check play in Telelever, wheel and swingarm bearings, renew if necessary. (replace wheel and swing arm bearings every 25,000 miles*)	☐		☐	
Adjust tire pressure to specification: Front ____ PSI Rear _____ PSI	☐	☐	☐	☐
Grease side stand/center stand pivots		☐	☐	
Check for smooth operation of throttle butterflies, tighten hose clamps to eliminate possibility of air leaks, synchronize throttle valves and adjust idle.	☐	☐	☐	
Final inspection with safety/operating check: • Lights, brake light, turn indicators, horn • Telltale and warning lights • Clutch, gear/neutral and side stand switch functions • Handbrake, footbrake and ABS; steering • Instruments and locks (including optional accessories/radio/alarm,etc.) • Test ride, visual quality check • Stamp Service & technical booklet	☐	☐	☐	☐

* invoiced as a separate item

⇩ Maintenance Complete, Sign and Record Mileage Below ⇩

Technician Signature _____ Date _____ Mileage Out _____